



MOUNTING SCREEN TO THE WALL:

- 1) DETERMINE SCREEN LOCATION AND MARK THE TOP AND BOTTOM CENTER OF THE SCREEN FRAME.
- 2) MEASURE ON A LEVEL PLANE ON TOP OF THE SCREEN FRAME FROM THE CENTER TO THE LEFT & RIGHT MINUS 10". FROM THIS POINT MEASURE 6 3/4" DOWN. THIS IS THE BOTTOM/CENTER POINT OF THE TOP WALL BRACKETS AS SHOWN IN SECTION A-A.
- 3) FROM THE BOTTOM CENTER POINT OF THE SCREEN FRAME, MEASURE 1 1/4" UP. THIS IS THE BOTTOM CENTER POINT OF THE BOTTOM WALL BRACKET AS SHOWN IN SECTION B-B.

SPECIAL NOTE: USE PROPER AND RATED WALL ANCHORS. MINIMUM CAPACITY SHOULD BE 250 LBS. TOTAL.

- 4) RAISE THE SCREEN TO THE WALL. OVERLAP THE COINCIDING WALL MOUNT BRACKET WITH THE APPROPRIATE MOUNTING GROOVE ON THE BACK OF THE SCREEN AND LOWER THE SCREEN INTO PLACE.

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF VUTEC CORPORATION AND REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF VUTEC CORPORATION IS PROHIBITED

VUTEC CORPORATION
11711 W. Sample Road, Coral Springs, FL 33065

DRAWN BY
03/31/17 TM
CHECKED BY

DESCRIPTION
**SilverStar SSX
INSTALLATION INSTRUCTIONS**

DRAWING NO.
SSX INSTALLATION
SCALE: 1/16
REV **A**